

# AlphaSorb® Fabric Wrapped Acoustic Foam Bass Traps

## Installation

AlphaSorb® Fabric Wrapped Bass Traps can be mounted in any 90° corner between two walls or a wall and a ceiling.

- The trap can be attached directly to the surfaces using hook and loop Velcro. Note: For best results, clean wall surfaces before applying the pressure sensitive adhesive backing on the Velcro to the wall or use a hot glue gun to attach the Velcro to the wall.
- Water-based construction adhesive can also be used to adhere the corner trap in place. Note: We recommend Loctite® Power Grab or another water-based construction adhesive which can be used in any standard caulk gun.
- If there is no 90° corner available, or if the corner is not suitable, AlphaSorb® Fabric Wrapped Bass Traps can be stacked in a freestanding configuration.



Revised: 2025-04-30